

Tall Alto / Tenor Sax Stand



SXS7401B / 12575



Features and Benefits

Designed for use when standing, this extra tall stand holds an alto or tenor saxophone at a height that can be easily reached without having to bend over. The adjustable upper and lower yoke support securely hold the saxophone in place. The lower cross yoke can be adjusted for two positions to ensure that your instrument is cradled and balanced securely. The tripod folding leg base and removable yoke assembly make this stand ideal for storage and travel.

Product Specifications

Application: Alto / tenor saxophone

Height Adjustment: 36" - 48"

Base Spread: 22"

Number of Instruments Held: 1

Color: Black

